


How to read your engine model



Specifications are subject to change without notice.  
Power based on SAE J1995 Gross Power (without air cleaner, muffler, fan, with alternator without load)

The data on this chart are for information purposes only and do not represent binding values.

For details ask your nearest Kubota dealer.

Date: October 2021

● **Kubota Corporation**

2-47, Shikitsuhigashi 1-Chome,  
Naniwa-Ku, Osaka 556-8601, Japan  
[www.kubota.com](http://www.kubota.com)  
<http://global.engine.kubota.co.jp>

● **Kubota Europe S.A.S.**

19, rue Jules Verceyusse  
CS 50088  
95101 Argenteuil Cedex, France  
Phone: +33 01 34 26 34 34  
E-mail: [ke\\_g.moteur@kubota.com](mailto:ke_g.moteur@kubota.com)  
[www.kubota-eu.com](http://www.kubota-eu.com)

● **Kubota (Deutschland) GmbH**

Senefelderstraße 3 - 5  
63110 Rodgau, Germany  
Phone: +49 6106 873-0  
E-mail: [motoren@kubota.de](mailto:motoren@kubota.de)  
[www.kubota-eu.com](http://www.kubota-eu.com)


● **Kubota (U.K.) Limited**

Dormer Road  
Thame OX9 3UN, United Kingdom  
Phone: +44 01844 268150  
E-mail: [kuk\\_g.engines@kubota.com](mailto:kuk_g.engines@kubota.com)  
[www.kubota-eu.com](http://www.kubota-eu.com)

For Earth, For Life  
**Kubota**

# SI Engine Guide

(Spark Ignited)



**Kubota,  
The  
Answer**




Stage 5 (< 1L and > 1L)



USA EPA Phase 3/CARB Phase 3/4 (< 1L)



USA EPA Tier 2/CARB Tier 3 (> 1 L)



Several dual fuel and multiple fuel engine models are available. Please ask your Kubota Dealer.  
 Long-maintenance variants available subject to application.